## With "Fan" set to...










## and function set to...

| | | |
|---|---|---|
|   The A/C will cool the camper until it reaches the set temperature | The A/C will run at the "High" setting continuously* | The A/C will run at the "Low" setting continuously* |
|   The furnace will heat the camper until it reaches the set temperature | Both furnace and heat pump (on "High") turn on; furnace shuts off at set temperature, heat pump fan runs continuously | Both furnace and heat pump (on "High") turn on; furnace shuts off at set temperature, heat pump fan runs continuously |
|   The heat pump will heat the camper until it reaches the set temperature | The heat pump will run at the "High" setting continuously* | The heat pump will run at the "Low" setting continuously* |

## and function left on "Fan"

| | | |
|---|---|---|
|   Nothing happens (or, if the fan was running, it will shut off) | The fan (with no cooling) will run at the "High" setting continuously* | The fan (with no cooling)will run at the "Low" setting continuously* |